

SWITCHING SYSTEM 110




FIG. 1

FIG. 2A





FIG. 2B






FIG. 3

400
⚡

FIGURE 4 ⚡

404
⚡408
⚡

⚡ 412

A 2	Play Review Listen to	New	messages	11
B 2	Play Review Listen to	Saved	messages	12
C 2	Delete Erase	message		337
D 2	Save	message		339
E 2	Next Skip	message		#
F 2	Repeat Replay	message		334
G 2	Envelope	Information		335
H 2	Forward	message		336
I 2	Record	a	Reply	338
J 2	Record	a	New Message	2
K 2		Options		0
L 2		Mark it	Urgent	2
M 2			Confirmation	3
N 2		Mark it	Private	1
O 2		Send	message	#
P 2	Main Menu			33*
Q 2	Cancel Finished			*
R 2	Pound			#
S 2	Star			*
T 2	Goodbye Hang-up Exit			***
U 2	Any 4 digit number - i.e. mailbox or ext.			4 digit number